

Command Reference Manual

MODEL : PMC-xxxx (Piezoelectric Motor Controller)

VER. 105

Piezoelectric Technology Co., Ltd.

#501 Sinnae Technotown, 485 Sangbong1 – dong,
Jungrang –gu, Seoul, Korea, 131 - 863

Tel. +82- 2 - 3421 – 0370~3 , Fax. +82 – 2 - 3421 – 0374

<http://www.piezo-tech.com>

Revision History

Version	Date	Changes	Status	Author/Approver
100	2013/03/21	First revision	draft	Jongmin Choi
101	2013/04/16	Added Velocity command	draft	Jongmin Choi
102	2013/08/26	Added PT Table	draft	Jongmin Choi
103	2013/10/18	Added Alarm list Added Received command from PMC1202 Modified command list	draft	Jongmin Choi
104	2013/10/28	Added MR-Encoder and MR-Sensor error of alarm list	draft	Jongmin Choi
105	2013/12/3	Added Encoder error of alarm list	draft	Jongmin Choi

- The information is subject to change without notice for technical improvement

CONTENTS

- 1 Communication Function of PMC-xxxx**
- 2 Communication Specification**
- 3 Communication Data Format**
- 4 Command List**
 - 4.1 Moving Commands**
 - 4.2 Open-Loop Commands**
 - 4.3 Status Commands**
 - 4.4 Alarm list**
 - 4.5 Configuration Commands**
 - 4.6 Control Filter Commands**
 - 4.7 Position-Time Commands**
- 5 Contact Information**

1. Communication Function of PMC-xxxx

1-1. Connecting the PC and PMC-xxxx Controller allows following operations from the PC :

- 1-1-1. Writing and reading out the setting value
- 1-1-2. Reading out the measurement value
- 1-1-3. Reading out the control output status
- 1-1-4. Operating the control input

2. Communication Specification

Baud rate	115200 bps
Transmission code	ASC II
Data length	8 bit
Stop bit length	1 bit
Parity check	Nil
Data classification	STX . ETX

3. Communication Data Format (Command)

Type	STX	COMMAND	ETX
Send to controller	'>'		'Wr'
Receive from controller	'<'		'Wr'

Type	STX	COMMAND	SPACE1	PARAMETER1	ETX
Send to controller	'>'		0x20	optional	'Wr'
Receive from controller	'<'		0x20	optional	'Wr'

Type	STX	COMMAND	SPACE1	PARAMETER1	SAPCE2	PARAMETER2	ETX
Send to controller	'>'		0x20	optional	0x20	optional	'Wr'
Receive from controller	'<'		0x20	optional	0x20	optional	'Wr'

STX	The code showing the head of transmit data/received data ('>' = 0x3e) ('<' = 0x3c).
COMMAND	Selects from the column of command on the command list to set.
SPACE1	Shows the separation between Command and Parameter1.
PARAMETER1	Numeric-string1 which is optional.
SPACE2	Shows the separation between Parameter1 and Parameter2.
PARAMETER2	Numeric-string1 which is optional.
ETX	The code showing the completion of transmit data/received data ('Wr' = 0x0d).

4. Command list

4-1. Motion Commands (Point to Point – PTP)

Command	Parameter1	Parameter2	Description
ma	-2,147,000,000 ~ +2,147,000,000	-	Move to the absolute target position, [counts]. The target position can be specified absolute position, using the absolute position parameter. 1) Parameter1 : Assigning an absolute target position, [counts] 2) Send to controller : printf(">ma 1000Wr"); 3) Receive from controller : printf("<ma 1000Wr");
mr	-2,147,000,000 ~ +2,147,000,000	-	Move to the relative target position, [counts]. The target position can be specified relatively to the current desired position, using the relative position parameter. 1) Parameter1 : Assigning an relative target position, [counts] 2) Send to controller : printf(">mr 1000Wr"); 3) Receive from controller : printf("<mr 1000Wr");
home	-	-	Move to the home position. 1) Send to controller : printf(">homeWr"); 2) Receive from controller : printf("<homeWr");
stop	-	-	Aborts the motion immediately. 1) Send to controller : printf(">stopWr"); 2) Receive from controller : printf("<stopWr");

4-2. Open-Loop Commands

Command	Parameter1	Parameter2	Description
openmode	0/1	-	Define mode of open-loop 1) 0 : Time(ms) [default], 1 : pulse 2) Send to controller : printf(">openmode 0Wr"); 3) Receive from controller : printf("<openmode 0Wr");
duration	1 ~ 600,000	-	Define the moving on-time(pulse). 1) Send to controller : printf(">duration 1000Wr"); 2) Receive from controller : printf("<duration 1000Wr");
interval	1 ~ 600,000	-	Define the time between the start of each step 1) Parameter1 : step interval (unit : ms) 2) Send to controller : printf(">interval 1000Wr"); 3) Receive from controller : printf("<interval 1000Wr");
cycle	1 ~ +2,147,000,000	-	Define the optional number of run. 1) Send to controller : printf(">cycle 10Wr"); 2) Receive from controller : printf("<cycle 10Wr");
re	-	-	Motor runs in reverse. 1) Send to controller : printf(">reWr"); 2) Receive from controller : printf("<reWr");
fo	-	-	Motor runs forward. 1) Send to controller : printf(">foWr"); 2) Receive from controller : printf("<foWr");
bi	-	-	Move to both direction. 1) Send to controller : printf(">biWr"); 2) Receive from controller : printf("<biWr");

4-3. Status Commands (It is a read only commands, indicating the recording status.)

Command	Parameter1	Parameter2	Description
cp	-	-	This command reports the actual controller position (Encoder Value). 1) Send to controller : printf(">cpWr"); 2) Receive from controller : printf("<cp %ldWr", current_position);
status	-	-	Get the alarm status. 1) Send to controller : printf(">statusWr"); 2) Receive from controller : printf("<status %dWr", alarm_status);
velr	-	-	Get the velocity value. 1) Send to controller : printf(">velrWr"); 2) Receive from controller : printf("<vel %dWr", velocity);
inform	-	-	Reports the configuration setting of controller 1) Send to controller : printf(">informWr"); 2) Receive from controller : printf("<freq %ldWr", frequency); printf("<volt %dWr", volta); printf("<encoder %dWr", encoder_type); printf("<resolution %ldWr", resolution); printf("<encswap %dWr", encoder_swapped); printf("<vel %ldWr", velocity); printf("<offset %ldWr", Home_offset); printf("<lm %ldWr", reverse_limit); printf("<lp %ldWr", forward_limit); printf("<st %ldWr", stroke);
ver	-	-	Get the controller firmware version. 1) Send to controller : printf(">verWr"); 2) Receive from controller : printf("<ver %ld %ldWr", yymmdd, version)

4-4. Alarm list (It is a read only)

When power-on, the status of PMC-1202 is reset to 0x1000.

Alarm bit (Hex)	Function Name	Description
8000	MOTOR_RUNNING	1 = Motor is running
4000	-	
2000	-	
1000	HOME_MISSING	1 = Home position is not known
800	-	
400	-	
200	-	
100	ILLEGAL_CMD	1 = The command was improperly formatted (When next command received, bit is zero)
80	PARAMETER_ERR	1 = The parameter is out of range (When next command received, bit is zero)
40	MR_ENCODER_ERR	1 = MR-Encoder error
20	MR_SENSOR_ERR	1 = MR-Sensor error
10	ENCODER_ERR	1 = Encoder error (swapped line, connection missing, encoder error)
8	POSITION_ERR	1 = Position error - Resolution: 5um (Target position ± 3 pulse \neq current position) - Resolution: 1um (Target position ± 3 pulse \neq current position) - Resolution: 100nm (Target position ± 5 pulse \neq current position) - Resolution: 10nm (Target position ± 10 pulse \neq current position)
4	ENCODER_Z_ERR	1 = Z signal error (Contact to Piezoelectric Technology Co., Ltd)
2	-	
1	OVER_TEMP	1 = The specified temperature is exceeding (After 3minute, the PMC-1202 is normal operation)

4-5. Configuration Commands

Command	Parameter1	Parameter2	Description
freq	20 ~ 100	-	Define the driving frequency. 1) Parameter 1 : Driving frequency (20~100KHz) 2) Send to controller : printf(">freq 68Wr"); 3) Receive from controller : printf("<freq 68Wr");
duty	1~48	-	Define the duty(Open-loop only) 1) Parameter 1 : Duty (1 ~ 48%) 2) Send to controller : printf(">duty 25Wr"); 3) Receive from controller : printf("<duty 25Wr");
volt	16 ~ 35	-	Define the voltage. 1) Parameter 1 : Voltage (unit : V) 2) Send to controller : printf(">volt 30Wr"); 3) Receive from controller : printf("<volt 30Wr");
encoder	1 ~ 4	-	Define the encoder type. 1) Parameter 1 : Encoder type 1-1) A/B signal : 1 1-2) A/B/Z signal : 2 1-3) Opt-pass : 3 1-4) MR-Sensor : 4 1-5) MR-Encoder : 5 2) Send to controller : printf(">encoder 1Wr"); 3) Receive from controller : printf("<encoder 1Wr");
resolution	10 100 1000 5208	-	Define the resolution of encoder. 1) Parameter 1 : nanometer (unit : nm) 2) Send to controller : printf(">resolution 1000Wr"); 3) Receive from controller : printf("<resolution 1000Wr");
encswap	0 ~ 1	-	Swap Encoder A and Encoder B inputs 1) Parameter 1 : Input is inverted or not inverted 2) Send to controller : printf(">encswap 1Wr"); 3) Receive from controller : printf("<encswap 1Wr");
vel	3 ~ 40	-	Define the velocity 1) Parameter 1 : Velocity (unit : mm/s) 2) Send to controller : printf(">vel 10Wr"); 3) Receive from controller : printf("<vel 10Wr");
reset	-	-	Warm-start, it is same as the cold-start. 1) Send to controller : printf(">resetWr"); 2) Receive from controller : printf("<resetWr");
offset	-2,147,000,000 ~ +2,147,000,000	-	Define the offset of HOME position. 1) Send to controller : printf(">offset 100Wr"); 2) Receive from controller : printf("<offset 100Wr");
save	-	-	Save the current configuration to the internal flash memory permanently 1) Send to controller : printf(">saveWr"); 2) Receive from controller : printf("<saveWr");

4-6. Control filters Commands

Command	Parameter1	Parameter2	Description
kp	0 ~ +32767	-	KP is the position loop gain. 1) Parameter 1 : Proportional position gain. 2) Send to controller : printf(">kp 100Wr"); 3) Receive from controller : printf("<kp 100Wr");
ki	0 ~ +32767	-	KI is the velocity loop integral term gain. 1) Parameter 1 : Integral gain, in velocity loop. 2) Send to controller : printf(">ki 90Wr"); 3) Receive from controller : printf("<ki 90Wr");
kd	0 ~ +32767	-	KD is the velocity loop overall gain multiplier 1) Parameter 1 : Derivative gain, in velocity loop. 2) Send to controller : printf(">kd 10Wr"); 3) Receive from controller : printf("<kd 10Wr");
kf	0 ~ +32767	-	IIR filter 1) Parameter 1 : Specifies the parameter of position controller IIR filter. 2) Send to controller : printf(">kf 1000Wr"); 3) Receive from controller : printf("<kf 1000Wr");

- ♣ Under most circumstances, this commands is used only by the tuning environment.
- ♣ This commands is not supported by the standard firmware version of the controller.
- ♣ Please consult Piezoelectric Technology experts for more information.

4-7. Position-Time Commands

Command	Parameter1	Parameter2	Description
pt1~pt50	-2,147,000,000 ~ +2,147,000,000	1 ~ 600,000	Position-Time Table_x 1) Parameter 1 : Assigning an absolute target position, [counts] 2) Parameter 2 : step interval (unit : ms) 3) Send to controller : printf(">pt1 100 10Wr"); 4) Receive from controller : printf("<pt1 100 10Wr"); 5) Send to controller : printf(">pt2 -100 100Wr"); 6) Receive from controller : printf("<pt2 -100 100Wr"); 7) Send to controller : printf(">pt50 1000 100Wr"); 8) Receive from controller : printf("<pt50 1000 100Wr");
delete	0 ~ 50	-	Delete the PT table. (0 : all clear) 1) Send to controller : printf(">delete 10Wr"); 2) Receive from controller : printf("<delete 10Wr");
save	-	-	Save the current condition to the internal flash memory permanently. 1) Send to controller : printf(">saveWr"); 2) Receive from controller : printf("<saveWr");
ptread	-	-	Reports the actual controller PT table. 1) Send to controller : printf(">ptreadWr"); 2) Receive from controller : printf("<ptread %d %d %dWr", number, position, interval);
step	0 ~ +2,147,000,000	-	Define the optional number of run. (0 : unlimited) 1) Send to controller : printf(">step 100Wr"); 2) Receive from controller : printf("<step 100Wr");
ptstart	-	-	Motor runs. 1) Send to controller : printf(">ptstartWr"); 2) Receive from controller : printf("<ptstartWr");
stop	-	-	Aborts the motion immediately. 1) Send to controller : printf(">stopWr"); 2) Receive from controller : printf("<stopWr");

5. Contact Information

Contact your local distributor or Piezoelectric Technology Co., Ltd.

5-1. Head Office

Room 501, 503 Sinnae Technotown, 485 Sangbong1dong, Jungrang-gu, Seoul, Korea. 131-863

Tel: +82-2-3421-0370~3

Fax: +82-2-3421-0374

Web site: www.piezo-tech.com

Email: piezo-tech@piezo-tech.com